





Find the right firmware version to update your Xovis sensor

		Update 3.9 / Non-AI	Update 4.2 / AI-powered
PC2S 	PC2S PC2S-L PC2S-UL	No Non-AI firmware update not possible	Yes Comes with AI firmware only
PC2R 	PC2R PC2R-L PC2R-UL	Yes Non-AI firmware update possible Comes with non-AI firmware by default	Yes Upgrade to AI firmware optional Later downgrade to non-AI firmware not possible
PC2R-0 	PC2R-0 PC2R-0-L PC2R-0-UL	Yes Non-AI firmware update possible Comes with non-AI software by default	Yes Upgrade to AI firmware optional Later downgrade to non-AI firmware not possible
PC2 PC3 PC3-0 	PC2 PC2-L PC2-UL PC3 (-0) PC3-L (-0) PC3-M1 (-0) PC3-M2 (-0) PC3-H (-0) PC3-UH (-0)	Yes Comes with non-AI firmware by default	No Upgrade to AI firmware not possible